


Mounting

To mount the V3 Zone Controller:

- 1. On the mounting location, mark and then drill two 3/16-inch (0.1875-inch) holes 3.5 inches apart from and parallel to each other for the plastic-ribbed anchors and screws. See the drawing below.
- 2. Insert the plastic-ribbed anchors into the prepared holes.
- 3. Install the #6 screws into the plastic-ribbed anchors and leave approximately 1/8-inch gap from the screw head to the wall.
- 4. Determine which sides of the V3 Zone Controller will be facing up, and then slide the V3 Zone Controller down over the screws to latch onto the screws.



Contacting CyberData

Corporate Headquarters

CyberData Corporation
3 Justin Court
Monterey, CA 93940, USA

Phone: 831-373-2601
Fax: 831-373-4193
<http://www.cyberdata.net/>

Sales: (831) 373-2601 ext. 334
Support: 831-373-2601 ext. 333
Support Website: <http://support.cyberdata.net/>
RMA Department: (831) 373-2601 ext. 136
RMA Email: RMA@CyberData.net
RMA Status: <http://support.cyberdata.net/>
Warranty Information: <http://support.cyberdata.net/>

Installation Quick Reference
VoIP V3 Zone Controller:
4-Port Audio Out
SIP Compliant
011171

The VoIP V3 Zone Controller with Audio-Out enables access to existing paging speakers through a VoIP phone system. The interface is designed to use a standard paging amplifier with audio inputs and supports paging up to 15 zone groups from a VoIP phone.

Product Specifications	
Power Requirement	PoE or +48VDC
LAN Speed	10/100 Mbps
Protocol	SIP compliant
Part Number	011171
Dimensions	6.11"L x 4.05"W x 1.15" H
Weight	1.2 lbs.



Getting Started

- Be sure that you have received all the parts described in the [Parts List](#) section.
- Download the *VoIP V3 Zone Controller Operations Guide* from the **Downloads** tab at following webpage: <http://www.cyberdata.net/voip/011171/>

Parts List


(1) VoIP Zone Controller - 4-Port Audio Out

(1) Mounting Kit




(2) #6 Plastic-Ribbed Anchors

(2) #6 x 1 1/2-inch Screws



Typical Zone Controller Setup Using the V3 Zone Controller



Setting Up the VoIP V3 Zone Controller

PoE 	To set up the V3 Zone Controller, connect the device to your network:
Non PoE (with 48 VDC power supply) 	Poe <ul style="list-style-type: none">For PoE, plug one end of an 802.3af Ethernet cable into the V3 Zone Controller Ethernet port. Plug the other end of the Ethernet cable into your network. See the figure on the left.
Chassis Ground 	Non-Poe <ul style="list-style-type: none">For Non-PoE, connect the V3 Zone Controller to a 48VDC power supply. See the figure on the left. Chassis Ground <ul style="list-style-type: none">If required, connect the earth grounding wire to the Chassis Ground. See the figure on the left.

Verifying Operations and Settings

Front View with LEDs 	<p>The round, BLUE Power Status LED on the front of the V3 Zone Controller comes on indicating that the power is on.</p> <p>The square, YELLOW Link LED above the Ethernet port indicates that the network connection has been established. The Link LED changes color to confirm the auto-negotiated connection speed:</p> <ul style="list-style-type: none">This LED is YELLOW at 10 Mbps.This LED is ORANGE at 100 Mbps. <p>The square, GREEN Activity LED above the Ethernet port blinks when there is network activity.</p> <p>The round, GREEN Status LED comes on after the device is booted and initialized. This LED blinks when the unit is operational.</p> <p>The square, GREEN Audio Activity LEDs turn on solid when a Zone is being paged.</p>
Back View with RTFM Switch 	<p>To restore the V3 Zone Controller's factory default settings:</p> <ol style="list-style-type: none">1. Use a paper clip to press and hold the RTFM switch while all of the indicator LEDs turn off. See the picture on the right.2. Continue to press the RTFM switch until after the indicator LEDs turn back on.3. Release the RTFM switch. All of the V3 Zone Controller settings will be restored to the factory default settings.4. You will hear the "Restoring defaults..." audio message play through all ports before the device reboots.