


Mounting


You have the option to use the following mounting template to mark, and then drill two 3/16-inch (0.1875-inch) holes for the mounting anchors.

To install and mount the Singlewire/SIP Paging Adapter:

- 1. Install the mounting anchors in the holes, and position the Singlewire/SIP Paging Adapter mounting holes over the anchors.



Dimensions



CyberData  
The IP Endpoint Company

Installation Quick Reference  
Singlewire/SIP Paging Adapter  
011280






Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address <sup>a</sup>	10.10.10.10
Web Access Username	admin
Web Access Password	admin
Subnet Mask <sup>a</sup>	255.0.0.0
Default Gateway <sup>a</sup>	10.0.0.1

a. Default if there is not a DHCP server present.

Getting Started

- Be sure that you have received all the parts described in the [Parts List](#) section.
- Download the *Operations Guide* at the **Downloads** page at following website:  
<http://www.cyberdata.net/voip/011280/>
- **WARNING:** This product should be installed by a licensed electrician according to all local electrical and building codes.
- **WARNING:** To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
- **WARNING:** The PoE connector is intended for intra-building connections only and does not route to the outside plant.
- **WARNING:** This enclosure is not rated for any AC voltages!

Parts List

<b>(1) Singlewire/SIP Paging</b> 	<b>(1) Mounting Template (see the last page)</b> 	<b>(1) Mounting Kit</b>  <b>(2) #6 x1.25-inch, PanHead, Phillips Sheet Metal Screw</b>  <b>(2) Plastic Anchors</b>
---	---	---


Contacting CyberData

<b>Corporate Headquarters</b>	
CyberData Corporation 3 Justin Court Monterey, CA 93940, USA	Sales: (831) 373-2601 ext. 334 Support: 831-373-2601 ext. 333 Support Website: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a> RMA Department: (831) 373-2601 ext. 136 RMA Email: <a href="mailto:RMA@CyberData.net">RMA@CyberData.net</a> RMA Status: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a> Warranty Information: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a>
Phone: 831-373-2601 Fax: 831-373-4193 <a href="http://www.cyberdata.net/">http://www.cyberdata.net/</a>	

Verifying Operations and Settings

When you plug in the Ethernet cable or power supply:

- The **GREEN/BLUE Status LED** and the **GREEN Paging LED** both blink at a rate of 10 times per second during the initial network setup.
- The round, **GREEN/BLUE Status LED** on the front of the Singlewire/SIP Paging Adapter comes on indicating that the power is on. Once the device has been initialized, this LED blinks at one second intervals.
- The square, **GREEN/AMBER Link LED** above the Ethernet port indicates that the network connection has been established. The Link LED changes color to confirm the auto-negotiated connection speed:
  - The Link LED is **GREEN** at 10 Mbps.
  - The Link LED is **AMBER** at 100 Mbps.
- The **GREEN Paging LED** comes on after the device is booted and initialized. This LED blinks when a page is in progress. You can disable **Beep on Initialization** on the **Device Configuration** page.



Setting Up the Singlewire/SIP Paging Adapter

**PoE**

A diagram showing an Ethernet cable being plugged into the Ethernet port of the Singlewire/SIP Paging Adapter.

**Non PoE with 48 VDC Power Supply**

A diagram showing a 48VDC power supply being plugged into the Ext. Power port of the Singlewire/SIP Paging Adapter.

**Chassis Ground**

A diagram showing a wire being connected to the chassis ground terminal on the bottom of the Singlewire/SIP Paging Adapter.

- To set up the device, connect the device to your network:
- Poe
- For PoE, plug one end of an 802.3af Ethernet cable into the Singlewire/SIP Paging Adapter Ethernet port. Plug the other end of the Ethernet cable into your network. See the figure on the left.
- Non-Poe
- For Non-PoE, connect the Singlewire/SIP Paging Adapter to a 48VDC power supply. See the figure on the left.
  - **Note:** Do not use both PoE and external power.
- Chassis Ground
- If required, connect the earth grounding wire to the Chassis Ground. See the figure on the left.

Connections

**Page Port Output Connections**

Pin	Description
1	Fault Sense Input (Common)
2	Fault Sense Input (Sense)
3	Positive 600-Ohm Audio Output <sup>a</sup>
4	Negative 600-Ohm Audio Output <sup>a</sup>
5	Audio Ground Reference
6	Relay Contact - Common <sup>b</sup>
7	Relay Contact - Normally Open <sup>b</sup>

a. The 600-Ohm audio output of the page port is also suited for interfaces with lower input impedances.  
b. 1 Amp at 30 VDC for continuous loads

A photograph of the Singlewire/SIP Paging Adapter with red lines pointing to various ports: 'RCA Line In' (jack), 'RCA Line Out' (jack), 'Page Port Output Power' (terminal block), and 'Ext. Power' (jack). Below the terminal block, pins 1 through 7 are labeled.

RTFM Switch

**To announce the IP address:**

1. Briefly press and then quickly release the RTFM switch.

**Note:** The IP address announcement can be heard if a speaker or amplified speaker is connected to the unit.

**To restore the factory default settings:**

1. Press and hold the **RTFM** switch while all the indicator lights turn off.

2. Continue to press the switch until after the indicator lights turn back on, and then release the switch.

**Note:** The “Restoring Defaults” announcement can be heard if a speaker or amplified speaker is connected to the unit.

3. All Singlewire/SIP Paging Adapter settings are restored to the factory defaults, and the unit reboots.

A photograph of the RTFM switch on the front of the Singlewire/SIP Paging Adapter.

Typical Configuration

