
Connecting and Sealing the Intercom (Service Loop Routing)



Securing the Intercom


Caution



Equipment Hazard: Do not use an electric or power screwdriver to fasten the faceplate and PCB assembly to the gang box. To prevent over-torque damage to the gasket, do not apply more than 10 inch-pounds force. Over-torquing will cause the gasket to tear, risk moisture intrusion, and effectively voi the manufacturer's warranty.

Note: To mount the intercom, use methods compliant with local electrical codes.

Note: More installation and mounting information is illustrated in the Operations Guide.



Contacting CyberData

Corporate Headquarters

CyberData Corporation 3 Justin Court

Monterey, CA 93940, USA

Phone: 831-373-2601 Fax: 831-373-4193

https://www.cyberdata.net/

Sales: 831-373-2601 ext. 334 Support: 831-373-2601 ext. 333

Support Website: https://support.cyberdata.net/

RMA Department Contact and Status: https://support.cyberdata.net/

Warranty Information: https://support.cyberdata.net/

The IP Endpoint Company

CyberData Installation Quick Reference


SIP-enabled h.264 Video Outdoor Intercom 011410



Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address ^a	192.168.1.23
Web Access Username	admin
Web Access Password	admin
Subnet Mask ^a	255.255.255.0
Default Gateway ^a	192.168.1.1

a. Default if there is not a DHCP server present.

Typical System Installation




Getting Started

- Download the Operations Guide PDF file, from the **Downloads** tab at the following webpage:
 - https://www.cyberdata.net/products/011410
- Create a plan for the locations of your Intercoms.
- WARNING: This product should be installed by a licensed electrician according to all local electrical and building codes.
- WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation
- WARNING: The PoE connector is intended for intra-building connections only and does not route to the outside plant.
- WARNING: This enclosure is not rated for any AC voltages!


Parts

Quick Reference




Features


Dimensions (Front and Side View)



Terminal Block Connections



RTFM Button



When the device is operational and linked to a network, you can use the Reset Test Function Management (RTFM) button (SW1 [see picture]) to announce the device's IP address or restore the device to the factory

To announce the device's current IP address:

can accept 16 AWG wire


Press and release the RTFM button within a five second window.

The device will use DHCP to obtain the new IP address (DHCP-assigned address or default to 10.10.10.10 if a DHCP server is not present).

To restore the device to factory default settings:

Press and hold the RTFM button for longer than five seconds until you hear the device announce that it is restoring the factory default settings.

Dimensions (Rear View and Mounting Holes)



Side Conduit Mounting Restrictions

Quick Reference

