

Wall Mounting Options



Maximum Recommended Wall Cutout Dimensions



Contacting CyberData

Sales: (831) 373-2601 ext. 334 Corporate Headquarters

Support: 831-373-2601 ext. 333 CyberData Corporation Web: http://www.cyberdata.net/support/contactsupportvoip.html

3 Justin Court RMA Dept: (831) 373-2601 ext. 136 Monterey, CA 93940, USA

Email: RMA@CyberData.net

Phone: 831-373-2601 Fax: 831-373-4193

Warranty information is available at: www.CyberData.net

Web: http://www.cyberdata.net/support/warranty/index.html




CyberData Installation Quick Reference

VoIP Indoor Intercom

SiP Compliant

011111*, RAL 9003, Signal White


*Replaces the 011030 number.



Factory Default Setting
DHCP
10.10.10.10
admin
admin
255.0.0.0
10.0.0.1

a. Default if there is not a DHCP server present.

Typical System Installation




Getting Started

- Download the VoIP Indoor Intercom Operations Guide PDF file from the following website address: http://www.cyberdata.net/products/voip/digitalanalog/intercomindoor/docs.html
- Create a plan for the locations of your Intercoms.
- Prior to installation, consult local building and electrical code requirements.
- WARNING: This enclosure is not rated for any AC voltages!


Intercom Parts

Quick Reference




RMA Status: http://www.cyberdata.net/support/rmastatus.html


Dimensions



Terminal Block Connections



Cable Connections



Gang Box Mounting Options

