



Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address ^a	10.10.10.10
Web Access Username	admin
Web Access Password	admin
Subnet Mask ^a	255.0.0.0
Default Gateway ^a	10.0.0.1

a. Default if there is not a DHCP server present.



Typical System Installation




Getting Started

- Download the *Operations Guide* PDF file, from the **Downloads** tab at the following webpage:
<https://www.cyberdata.net/products/011397-011398>
- Create a plan for the locations of your SIP Talk-Back Speakers.
- **WARNING:** This product should be installed by a licensed electrician according to all local electrical and building codes.
- **WARNING:** To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
- **WARNING:** The PoE connector is intended for intra-building connections only and does not route to the outside plant.
- **WARNING:** This enclosure is not rated for any AC voltages!



Parts

<p>(1) Speaker Assembly</p> <p>(1) Template</p> <p><i>* See the last page of this document</i></p>	<p>(1) Drop Ceiling Mounting Kit</p> <p>(3) #8 Nylon Thumb Nuts</p> <p>(3) #8 Fender Washers</p> <p>(3) 8-32 x 1 1/4" Mounting Screws</p>	<p>(1) Drywall Mounting Kit</p> <p>(3) Plastic Ribbed Anchors</p> <p>(3) #8 Sheet Metal Screws</p>
--	---	--


Dimensions and Connections




Connecting Power



Features



Mounting



Contacting CyberData

Corporate Headquarters

CyberData Corporation
3 Justin Court
Monterey, CA 93940, USA

Phone: 831-373-2601
Fax: 831-373-4193
<http://www.cyberdata.net/>

Sales: (831) 373-2601 ext. 334
Support: 831-373-2601 ext. 333
Support Website: <http://support.cyberdata.net/>
RMA Department: (831) 373-2601 ext. 136
RMA Email: RMA@CyberData.net
RMA Status: <http://support.cyberdata.net/>
Warranty Information: <http://support.cyberdata.net/>