


# Installation Quick Reference Singlewire/SIP Ceiling Tile Drop-In Speaker


## 011402

The Singlewire/SIP Ceiling Tile Drop-In Speaker is an adapter that is built for a CyberData SIP Speaker.

#### **Parts**



#### **Dimensions**




#### Procedure

To install the Singlewire/SIP Ceiling Tile Drop-In Speaker, refer to the drawing in the "Installing the Singlewire/SIP Ceiling Tile Drop-In Speaker" section on the other side of this document. Complete the following steps:

- 1. Remove the ceiling tile from the ceiling (T-tracks).
- 2. For 2ft. x 4 ft. tile space, cut the ceiling tile to 35-1/2" long or for a 2 ft. x 2ft. tile space, cut to 11-1/2" long.
- 3. Place the speaker in the ceiling with the tile support rail crossbar facing the ceiling tile opening.
- 4. Drop in the tile.

#### Installing the Singlewire/SIP Ceiling Tile Drop-In Speaker



### Contacting CyberData

Corporate Headquarters

CyberData Corporation Sales: (831) 373-2601 ext. 334
3 Justin Court Support: 831-373-2601 ext. 333

Monterey, CA 93940, USA

Support Website: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a>
RMA Department: (831) 373-2601 ext. 136

Phone: 831-373-2601 RMA Email: RMA@CyberData.net Fax: 831-373-4193 RMA Status: http://support.cyber

Fax: 831-373-4193 RMA Status: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a>
Warranty Information: <a href="http://support.cyberdata.net/">http://support.cyberdata.net/</a>