




AT&T PagePac 20 PowerMate




J1 PINOUT	
1	—
2	(BLK)
3	(RED)
4	(GRN)
5	(YEL)
6	—



SIP Paging Adapter Connections



RJ11



Notes

CyberData SIP Paging Adapter's Page Port output connects to the PAGE INPUT on the AT&T PagePac 20 PowerMate using an RJ11 modular connector for single-zone paging. Talkback is not supported.

It will be necessary to use the SIP Paging Adapter's normally open relay contacts in addition to the Page Port connection for contact closure.