



## **Notes**

Select Enable relay on local audio on the Device Configuration setup page of the Singlewire Paging Adapter.

2-conductor, shielded speaker wire is recommended.

Pin	Description
1	Fault Sense Input (Common).
2	Fault Sense Input (Sense).
3	Positive 600-Ohm Audio Output <sup>a</sup>
4	Negative 600-Ohm Audio Output <sup>a</sup>
5	Audio Ground Reference.
6	Relay Contact - Common <sup>b</sup>
7	Relay Contact - Normally Open <sup>b</sup>
also : impe	e 600-Ohm audio output of the page port is suited for interfaces with lower input dances. mp at 30 VDC for continuous loads.