


### Speco PL200M Amplifier

### SIP Paging Server Connections



### Page Port Output Connections

Pin	Description
1	Fault Sense Input (Common).
2	Fault Sense Input (Sense).
3	Positive 600-Ohm Audio Output <sup>a</sup>
4	Negative 600-Ohm Audio Output <sup>a</sup>
5	Audio Ground Reference.
6	Relay Contact - Common <sup>b</sup>
7	Relay Contact - Normally Open <sup>b</sup>

a. The 600-Ohm audio output of the page port is also suited for interfaces with lower input impedances.  
 b. 1 Amp at 30 VDC for continuous loads.

### Notes

On the **Device** webpage, check the **Activate Relay on local audio** box, and then click on **Save** and **Reboot**.

In order to have any multicast group page also play analog audio out through the RCA plug and terminal strip, select **Yes** for **Lineout** next to the desired zone on the **PGROUPS** page.

2 conductor, shielded speaker wire is recommended.