

Contacting CyberData

Corporate Headquarters


CyberData Corporation **3 Justin Court** Monterey, CA 93940, USA

Phone: 831-373-2601 Fax: 831-373-4193 https://www.cyberdata.net/ Sales: 831-373-2601 ext. 334 Support: 831-373-2601 ext. 333 Support Website: https://support.cyberdata.net/ RMA Department Contact and Status: https://support.cyberdata.net/ Warranty Information: https://support.cyberdata.net/

berData	Installation Qu
Endpoint Company	SIP Outdo
	SIP Compliar
	011491
	Parameter
0	
	IP Addressing
For HELP	IP Address ^a
	Web Access Username
	Web Access Password
Press Button	Subnet Mask ^a
	Default Gateway ^a
٢	a. Default if there is no

Typical System Installation


The IP



Getting Started

- https://www.cyberdata.net/products/011491
- Create a plan for the locations of your SIP Outdoor Call Buttons.
- instructions.
- WARNING: This enclosure is not rated for any AC voltages!

Parts



lick Reference oor Call Button nt


Factory Default Setting
DHCP
192.168.1.23
admin
admin
255.255.255.0
192.168.1.1

ot a DHCP server present.


Download the SIP Outdoor Call Button Operations Guide PDF file, from the SIP Outdoor Call Button product page at:

• WARNING: This product should be installed by a licensed electrician according to all local electrical and building codes. WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation

WARNING: The PoE connector is intended for intra-building connections only and does not route to the outside plant.



RTFM Button



Wall Mounting Options



