



Notes

- 1. CyberData SIP Paging Adaptor's RCA line level output can connect to any of the eight LINE inputs on the Crown 180MA/280MA/1160MA amplifier.
- 2. Move the **MIC/LINE** switch to the **LINE** position for the respective input.
- 3. Connect the SIP Paging Adapter's relay contact terminals to COM and CH1 AMP1 for mute control over all other amp music channels. When using contact closure, check the box to **Enable** relay on local audio on the Device Configuration page of the web interface.
- 4. 2-conductor, shielded speaker wire terminated with RCA male connectors is recommended.

SIP Paging Adapter Output Connections

Pin	Description
1	Fault Sense Input (Common).
2	Fault Sense Input (Sense).
3	Positive 600-Ohm Audio Output
4	Negative 600-Ohm Audio Output
5	Audio Ground Reference.
6	Relay Contact - Common
7	Relay Contact - Normally Open