



# CyberData and CyberSoftPhone Point to Point Configuration Guide

Document Part #931405C

**CyberData Corporation** 

3 Justin Court Monterey, CA 93940 (831)-373-2601

## **Copyright Notice**

© 2022, CyberData Corporation, ALL RIGHTS RESERVED. This configuration guide and related materials are the copyrighted property of CyberData Corporation. No part of this configuration guide or related materials may be reproduced or transmitted, in any form or by any means (except for internal use by licensed customers), without prior express written permission of CyberData Corporation. This configuration guide, and the products, software, firmware, and/or hardware described in this configuration guide are the property of CyberData Corporation, provided under the terms of an agreement between CyberData Corporation and recipient of this configuration guide, and their use is subject to that agreement and its terms.

DISCLAIMER: Except as expressly and specifically stated in a written agreement executed by CyberData Corporation, CyberData Corporation makes no representation or warranty, express or implied, including any warranty or merchantability or fitness for any purpose, with respect to this configuration guide or the products, software, firmware, and/or hardware described herein, and CyberData Corporation assumes no liability for damages or claims resulting from any use of this configuration guide or such products, software, firmware, and/or hardware. CyberData Corporation reserves the right to make changes, without notice, to this configuration guide and to any such product, software, firmware, and/or hardware.

OPEN SOURCE STATEMENT: Certain software components included in CyberData products are subject to the GNU General Public License (GPL) and Lesser GNU General Public License (LGPL) "open source" or "free software" licenses. Some of this Open Source Software may be owned by third parties. Open Source Software is not subject to the terms and conditions of the CyberData COPYRIGHT NOTICE or software licenses. Your right to copy, modify, and distribute any Open Source Software is determined by the terms of the GPL, LGPL, or third party, according to who licenses that software. Software or firmware developed by CyberData that is unrelated to Open Source Software is copyrighted by CyberData, subject to the terms of CyberData licenses, and may not be copied, modified, reverseengineered, or otherwise altered without explicit written permission from CyberData Corporation.


TRADEMARK NOTICE: CyberData Corporation and the CyberData Corporation logos are trademarks of CyberData Corporation. Other product names, trademarks, and service marks may be the trademarks or registered trademarks of their respective owners.

## **Revision Information**


Version	Date	Revision	Valid for FW	Valid for Models
1.0	28-Apr-17	Initial Version	1.0.1	011410,
				011414
1.1	1-Sept-22	Update	1.4.1	011410
				011414

## Table of Contents

Copyright Notice	2
Revision Information	
Setup Diagrams	5
Intermediate Door Strike Relay	
Networked Dual Door Strike Relay	6
Parts List	7
Before you start	7
Configuration: Soft Phone	8
Configuration: Intercom	9
Making a Call with the CyberSoftPhone	
Internal Relay	
External Relay	11
Frequently asked questions	11
Contact CyberData Corporation	



### Networked Dual Door Strike Relay



## Parts List

Product Name	Product Number		
SIP-enabled h.264 Video Outdoor Intercom	<u>011410</u>		
Or	Or		
SIP-enabled h.264 Video Outdoor Intercom with Keypad	<u>011414</u>		
Networked Dual Door Strike Relay	<u>011375</u>		
Or	Or		
Door Strike Intermediate Relay Module	<u>011269</u>		
PoE Power Injector 802.3af	<u>010867</u>		
CyberSoftPhone	<u>Download</u>		
User Supplied	Operating System		
Windows PC	XP, Vista, 7, 8 or 10		
Generic Switch	-		
Generic Door Strike	-		

### Before you start

This guide will detail the configuration of the CyberData SIP-enabled h.264 Video Outdoor Intercom and SIP-enabled h.264 Video Outdoor Intercom with Keypad to work in point to point mode with the CyberData softphone; CyberSoftPhone. CyberSoftPhone is a free softphone made for Windows. 64 Characters have released similar client for Mac although under the name Telephone. This guide will focus on configuration for a windows client.

Note: For point to Point mode to work the intercom and PC must be on the same network.


## Configuration: Soft Phone

CyberSoftPhone is extremely easy to install and setup. The soft client is available for <u>download</u> from our website. Once downloaded, please run the exe file to begin installation.

### \*Note\* CyberSoftPhone is compatible with Windows XP, Vista, 7, 8, and 10.

First select the language and click OK. The program will then open the installer. Press next to move to choosing a start menu folder, by default the program will create its own folder. This is acceptable for most users; so, unless otherwise desired please press install.

## \*Note\* By default the program will install to C:\Program Files (x86)\CyberSoftPhone



The softphone will install very quickly as it is a very lightweight program. Once the program is installed, please run the client to ensure proper installation.

With the client open, please press "Menu" and navigate to the settings option, or press "ctrl + p" on your keyboard to open the settings menu. Please check the box Enable Local Account, then press save. Unless this box is checked, the program will expect a SIP account and will not be able to make or receive calls.

Note: Please write down the IP address of your computer as we will need it for the next step.

Settings	×	
Ringing Sound	I x	
Ring Device	Default 🔻	
Speaker	Default	
Microphone	Default 🔻	
Audio Codecs		
Available	Enabled	
Opus 16 kHz G. 729 8 kHz GSM 8 kHz AMR 8 kHz ILBC 8 kHz Speex 32 kHz Speex 16 kHz	G.711 u-law G.711 A-law G.722 16 kHz	
VAD EC	Force Codec for Incoming	
Camera	Default	
Video Codec	Default 🔹	
Disable H.	264 Bitrate 256	
Disable H.	263+ Bitrate 256	
Disable VP	P8 Bitrate 256	
DTMF Method	Auto	
Auto Answer	No	
Deny Incoming	No	
Directory of Users		
STUN Server		
Sound Events	Enable Log File	
Single Call Mode	Enable Local Account	
Random Position		
	Save Cancel	

## Configuration: Intercom

CyberData SIP-enabled h.264 Video Outdoor Intercoms are very easy to setup but require a little more work than the softphone. After powering up your intercom you will need to get the IP address of the device. There are a few different methods that can be used, the easiest of which is to press the "RTFM" button on the back of the intercom. Pressing this button will cause the intercom to announce its IP address. If the device has already been installed and there is no longer access to the back of the device, Cyberdata has created a tool to discover our products on your network. Simply download the VoIP discovery tool from our website and run the tool. After the tool has run a list will be populated with all the CyberData devices on your network. Select your intercom from the list and press the launch Browser button to open the webpage of your intercom.

\*Note\* The default login information for CyberData devices is Admin for username and Admin for password.

From the home screen of your intercom please navigate to the SIP tab. This is where we will do the necessary configuration.

First clear all information in the fields: **Primary SIP** Server, Primary SIP User ID, Primary SIP Auth. ID, Primary SIP Auth. Password. These fields must be blank.

Then set the **Dialout Extension** as the IP address of the PC.

Set the Extension ID as the name of the device.

Finally uncheck the box Register with a SIP server.

Then save and reboot the device.

Once the device has rebooted please make a test call to confirm that your device is working properly in Point to Point mode.

CyberData Corporation 3 Justin Court, Monterey, CA 93940 <u>www.cyberdata.net</u> P 831.373.2601 | F 831.373.4193

CyberData VoIP ProductDiscov	very Utility v1.	2.0			×
Product Type	IP Address	MAC Address	Serial Number	Device Name	
Unknown VoIP Product	10.10.1.174	00:20:F7:03:86:E3	410000115	Outdoor Intercom	
1					
Status: Idle		Scan	Det	ails Launch B	rowser
رل					

## CyberData Outdoor Intercom

SIP Settings		Nightringer Settings
Enable SIP operation:	*	SIP Server
Primary SIP Server:		SIP User ID:
Primary SIP User ID:	1	SIP Auth ID:
Primary SIP Auth ID:		SIP Auth Password:
Primary SIP Auth Password:	100	Re-registration Interval (In seconds): 360
Re-registration Interval (in second	ds):360	
Backup SIP Server 1:		Dial Out Settings
Backup SIP User ID:		Dial out Extension: 10.0.2.227
Backup SIP Auth ID:		Extension ID: Paul's Wee Intercom
Backup SIP Auth Password:	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Re-registration Interval (in second	55):360	
		Call Disconnection
Backup SIP Server 2:		Terminate Call after delay:0
Backup SP User ID:	8	
Backup SIP Auth ID:		
Backup SIP Auth Password:		RTP Settings
Re-registration interval (in second	ds): 360	RTP Port (even): 10500
Remote SP Port	5050	Jitter Buffer: 50
Local SIP Port:	5010	
		Save Reboot Topple Help
Outbound Proxy:	1	
Outbound Proxy Port	0	
Register with a SIP Server:		
Disable rport Discovery:		
Unregister on Boot:		



## Making a Call with the CyberSoftPhone

The CyberSoftPhone client is very intuitive and easy to use. To make a call from the client simply type in the IP address of the intercom. To make a video call press the small web camera button. To make an audio call, press the big call button.

To end a call from the softphone you **MUST** press the end call button from the client; closing the video window **will not** end the call.

## Internal Relay

Most CyberData products come equipped with a dry relay contact for triggering external controls. This is triggerable through DTMF when the intercom is in a call. The relay will

make a small click when activated. To test the relay from the web interface, navigate to the device tab and press "Test Relay" to activate the relay for 2 seconds. From the device tab, you will find all the configurable options regarding the onboard relay.

It is recommended to change the **Relay Pulse Code, Relay Activation Code**, and the **Relay Deactivation code**, as they are all in the default state and the codes are shared across our product line. Changing these values will make DTMF relay activation more secure.

## \*Note\* CyberData devices can handle up to 25 digit codes for DTMF relay activation.

Once the codes have been changed from their default values there are a few other

options that could prove useful depending on the use case. **Play tone during DTMF Activation** can be useful for loud environments where the user at the intercom may not be able to hear the click from the relay.

Test Audio Test Mikrophone Test Relay Toggle Help

Volu

SIP VE Multic Ring V Senso

Clo

vill		0.10.1.174	· ] @
elay ble / will	The	Reat tensor Audoffes	
Cy		Putdoor Int	ercom
me: 4 it Volume: 4 it Volume: 4 volume: 4 volume: 4 one Gain: 4	(a)	Relia y Settings Activate Relay with DYB Foote: Relia Philas Code: Relia Philas Code: Relia Datactivation Code: Pay tana a coning GTME Activation Activate Relia Duning Relia Activate Relia Duning Relia Relia Activate Relia Duning Relia Relia Duning Relia Relia Relia Relia Relia Relia Duning Relia Relia Relia Relia Relia Relia Relia Duning Relia Relia Relia Relia Relia Relia Relia Relia Duning Relia Relia Relia Relia Relia Relia Relia Duning Relia Relia Relia Relia Relia Relia Relia Relia Duning Relia Relia Relia Relia Relia Relia Relia Duning Relia	456
k Settings		Misc Settings	



## **External Relay**

If the internal relay cannot power your door lock or gate we also make external Relays such as the <u>Door</u> <u>Strike Intermediate Relay Module</u> or the <u>Networked Dual Door Strike Relay</u> or 'DDSR'. The main difference between the two relay modules is that the Door Strike Intermediate Relay is connected to the intercom via cable that is wired into the onboard terminal. The networked Dual Door Strike relay has the capability to handle two separate doors and does not require a direct connection to the intercom, although it must be on the same network as the associated intercom to function. Both devices can be triggered via DTMF with all intercom products and "Security Codes" with the Keypad Intercoms. The Door Strike Intermediate Relay can also be triggered by onboard sensors. Please see the operation guides on the specific product page for more information on the functionality of these devices.

## Frequently asked questions

### Does CyberSoftPhone support DTMF?

Yes, it supports DTMF via RFC-2833, in-band or SIP-INFO. CyberData devices use RFC 2833 so either 'Auto' or RFC-2833 will work.

### Can my Video Intercom still accept multicast pages?

Yes, although the device is in 'Point to Point' mode it can still receive multicast pages.

### Are there any advantages to using Point to Point mode?

The main advantage is that Point to Point configuration allows the device to be used in an environment that does not have SIP or VoIP infrastructure implemented.

### Why can't I call from my computer?

CyberSoftPhone requires a microphone and speakers to be attached to the PC to make a call, although the PC can receive calls without having a microphone or speakers. *The softphone* <u>**CANNOT**</u> *make calls to the intercom without both an audio input and output device. A speaker and desk mic could be used or a headset.* 

### Is a web camera required for video calls?

No, you can utilize the video function of CyberSoftPhone without a web camera as the program will send the connected device a 'color bar' image to display.

## Contact CyberData Corporation

### Sales:

For sales-related questions, please visit our Contact CyberData Sales web page for more

information.

### **Technical Support**

For Technical Support, please submit a ticket through our helpdesk at <u>support.cyberdata.net</u>.

#### **Documentation Feedback**

It is possible that any changes to our products could render this document obsolete. We welcome and encourage documentation feedback to ensure continued applicability.