

CyberData

The IP Endpoint Company

Using CyberData Devices with a GrandStream UCM6102 IP PBX



This is a sample of CyberData products, please visit cyberdata.net for a complete list.

Document: 931427A

Draft Date: 07/10/2017

Version 1

Copyright Notice

© 2017, CyberData Corporation, ALL RIGHTS RESERVED. This configuration guide and related materials are the copyrighted property of CyberData Corporation. No part of this configuration guide or related materials may be reproduced or transmitted, in any form or by any means (except for internal use by licensed customers), without prior express written permission of CyberData Corporation. This configuration guide, and the products, software, firmware, and/or hardware described in this configuration guide are the property of CyberData Corporation, provided under the terms of an agreement between CyberData Corporation and recipient of this configuration guide, and their use is subject to that agreement and its terms.

DISCLAIMER: Except as expressly and specifically stated in a written agreement executed by CyberData Corporation, CyberData Corporation makes no representation or warranty, express or implied, including any warranty or merchantability or fitness for any purpose, with respect to this configuration guide or the products, software, firmware, and/or hardware described herein, and CyberData Corporation assumes no liability for damages or claims resulting from any use of this configuration guide or such products, software, firmware, and/or hardware. CyberData Corporation reserves the right to make changes, without notice, to this configuration guide and to any such product, software, firmware, and/or hardware.

OPEN SOURCE STATEMENT: Certain software components included in CyberData products are subject to the GNU General Public License (GPL) and Lesser GNU General Public License (LGPL) “open source” or “free software” licenses. Some of this Open Source Software may be owned by third parties. Open Source Software is not subject to the terms and conditions of the CyberData COPYRIGHT NOTICE or software licenses. Your right to copy, modify, and distribute any Open Source Software is determined by the terms of the GPL, LGPL, or third party, according to who licenses that software. Software or firmware developed by CyberData that is unrelated to Open Source Software is copyrighted by CyberData, subject to the terms of CyberData licenses, and may not be copied, modified, reverse-engineered, or otherwise altered without explicit written permission from CyberData Corporation.

TRADEMARK NOTICE: CyberData Corporation and the CyberData Corporation logos are trademarks of CyberData Corporation. Other product names, trademarks, and service marks may be the trademarks or registered trademarks of their respective owners.

Table of Contents

Copyright Notice	2
Configuration Procedure: Extension Creation	4
Logging into the PBX	4
PBX Settings	4
Creating the Extension(s)	5
Configuring the Extension(s)	5
Configuring your CyberData Devices	8
Logging into the device	8
SIP Settings	9
Contact CyberData Corporation	10
Additional Resources	10

Configuration Procedure: Extension Creation

This section walks through creating the extension for CyberData Devices and the various settings that can be applied to the extensions.

Logging into the PBX

The UCM6102 features an LCD screen on the front of the device, this screen is used for notifications but when idle shows the IP address of the device. Please navigate to the IP address displayed on the screen, login to the device using the factory default login username and password: admin and admin.

PBX Settings

There are a couple settings on the PBX that need to be changed to ensure proper operation of CyberData Devices. Both settings are on the Type of Service (ToS) page, In-Band Ringing and DTMF Mode. To reach these settings first please navigate to the PBX tab. From the PBX tab please select SIP settings menu and finally ToS from the sub menu.

PBX → SIP Settings → ToS

The screenshot shows the GrandStream PBX web interface. The top navigation bar includes 'Status', 'PBX', 'Settings', and 'Maintenance'. The 'PBX' tab is selected. Below the navigation bar, the breadcrumb path is 'PBX >> SIP Settings >> ToS'. The left sidebar contains a menu with 'SIP Settings' and 'ToS' highlighted. The main content area is titled 'SIP ToS' and contains the following settings:

ToS for SIP:	None	ToS for RTP Audio:	None
ToS for RTP video:	None	Default Incoming/Outgoing Registration Time:	120
Max Registration/Subscription Time:	3600	Min Registration/Subscription Time:	90
Enable Relaxed DTMF:	<input type="checkbox"/>	DTMF Mode:	RFC2833
RTP Timeout:	90	RTP Hold Timeout:	100
RTP Keep-alive:	0	100rel:	Yes
Trust Remote Party ID:	<input type="checkbox"/>	Send Remote Party ID:	<input type="checkbox"/>
Generate In-band Ringing:	No	Server User Agent:	
Send Compact SIP Headers:	<input type="checkbox"/>		

At the bottom of the settings area, there are 'Cancel' and 'Save' buttons.

Generate In-Band Ringing: Please set this to No or Never. This setting uses early media for ringing on devices and this can cause issues with CyberData Devices.

DTMF Mode: Please set this to RFC2833. CyberData Devices transmit DTMF using RFC 2833.

Creating the Extension(s)

Now that the PBX is configured to work with CyberData Devices; let us now create extensions to be used by CyberData Devices. Depending on the amount of extensions desired there are multiple ways to create them, Single Extension, Bulk Extensions or Import via CSV. For this guide, we are going to walk through Bulk Extensions. Please select Batch Add SIP Extensions from the dropdown menu. This will result in a pop-up window with the various options.



Configuring the Extension(s)

The first important field, **Start Extension** is the first extension created, in this example we are using 1000. **Create Number** determines the number of extensions that are created. Now that we have determined the number of extensions to be created we must determine the **Permission** of the newly created extensions. For this example, we are using internal; this allows for calls only inside the network.

Note Please take care in determining the permission level of the extensions. Setting too high of a permission could result in toll fraud.

Enable Voicemail is enabled by default and can be disabled if desired, this is dependent on the use case. Typically, CyberData encourages the user to disable Voicemail for our devices as they do not require them, under normal circumstances. Dependent on the network infrastructure it may be beneficial to enable **Can Direct Media** this setting allows the device to send all media (Voice or Video traffic) directly to the endpoint. This will help reduce network traffic as the PBX will not be relaying the traffic between calling parties.

Please confirm that **DTMF Mode** is set to RFC 2833, we set this as default for the PBX so it should have propagated through to extensions.

Figure 1 Extension Settings Popup

Start Extension Create Number Permission Enable Voicemail Can Direct Media DTMF Mode

There are two more settings that are recommended to be changed. **Strategy** should be set to **Local Subnet Only**, to help further prevent toll fraud. If a remote user is being setup, use the setting: **A Specific IP Address** this will let the remote user register, but prevent non-authorized users from registering and making calls

Note Leaving Strategy set to the default value of Allow All could result in toll fraud and other related SIP based network attacks.

Finally, we must determine which codecs are available. CyberData Devices use PCMU, PCMA and G.722 to transmit audio in that order.

Note If you are using a CyberData Video Intercom or CyberData Video Intercom with Keypad, please include **h.264** in the Selected Codecs.

Figure 2 Bottom Half of Settings Pop-up

The screenshot shows the bottom half of a settings pop-up window. The window is titled "Seamless transfer privilege control". It contains several sections:

- Allowed to seamless transfer:** This section has two columns: "Available Extensions" (listing 1021, 1022, 1023, 1024, 1025, 1026) and "Selected Extensions" (empty).
- Other Settings:** This section contains several settings:
 - Fax Mode: None
 - SRTTP: Disabled
 - Skip Trunk Auth: No
 - Strategy: Local Subnet Only (highlighted with a blue box)
 - Local Subnet: 10.10.0.0 (Format: xxx.xxx.xxx.0 or :/16)
 - Enable T.38 UDPTL:
 - Bind PMS Room:
- Codec Preference:** This section has two columns: "Available Codecs" (listing AAL2-G.726-32, ADPCM, G.723, H.263, H.263p) and "Selected Codecs" (listing PCMU, PCMA, G.722).


At the bottom of the window are two buttons: "Cancel" and "Create Users".

Labels "Strategy" and "Codec Preference" with arrows point to their respective sections in the screenshot.

Once you have finished selecting the desired settings please press Create Users. There will then be a conformation popup, please press OK to create the extensions.

Figure 3 Create Extensions Conformation Pop-up

Now that the extensions have been created we can now begin registering CyberData Devices with the UCM 6102.




Configuring your CyberData Devices

Logging into the device

CyberData devices can be configured in many ways but this guide is going to focus on configuration by hand through the web interface of the device. The easiest way to discover CyberData devices on your network is to use our free VoIP discovery utility. Please see the [Additional Resources](#) section for a link to the download page.

Figure 4 VoIP Discovery Utility



The tool does not require installation and can simply be run after downloading. Please press the scan button to begin detection. This process typically takes about 5-10 seconds but can take upwards of 30 seconds depending on network congestion and the amount of devices. Once the tool has finished running it will be populated with the various different CyberData devices that are on your network. Simply select the device you want to configure from the menu and press Launch Browser.

CyberData uses default login information which is **admin** for both username and password.

Note CyberData recommends to change the default password once you have logged into your devices as using the default login information could leave your devices up for attack by outside users.

SIP Settings

Please navigate to the SIP tab by pressing the SIP menu bar.

SIP Operation and **Register with a SIP Server** are enabled by default.

Set the IP address of the UCM 6102 as the **Primary SIP server**.

Note It is also possible to use a Fully Qualified Domain Name (FQDN) in place of an IP Address.

Set the **Primary SIP user ID** as the desired extension.

Unless changed in the initial setup of the extension **Primary SIP Auth. ID** should also be the extension number.

Finally fill the **password** with the password generated by the PBX.

Note The Grandstream UCM 6102 requires each extension to have a password and it is recommended to use the random password generation to be secure as possible.

Please save and reboot your device to confirm that it has now registered with the PBX.

If your device has registered, it will show Registered in green next to Primary SIP Server on the home page of the device.

Figure 6 Registration Status

Primary SIP Server:	Registered
Backup Server 1:	Not registered
Backup Server 2:	Not registered
Nightringer Server:	Registered

Figure 5 SIP Settings

SIP Settings	
Enable SIP operation:	<input checked="" type="checkbox"/>
Register with a SIP Server:	<input checked="" type="checkbox"/>
Use Cisco SRST:	<input type="checkbox"/>
Primary SIP Server:	10.10.0.171
Primary SIP User ID:	1000
Primary SIP Auth ID:	1000
Primary SIP Auth Password:	*****
Backup SIP Server 1:	
Backup SIP User ID 1:	
Backup SIP Auth ID 1:	
Backup SIP Auth Password 1:	
Backup SIP Server 2:	
Backup SIP User ID 2:	
Backup SIP Auth ID 2:	
Backup SIP Auth Password 2:	
Remote SIP Port:	5060
Local SIP Port:	5060
Outbound Proxy:	
Outbound Proxy Port:	0
Disable rport Discovery:	<input type="checkbox"/>
Re-registration Interval (in seconds):	360
Unregister on Boot:	<input type="checkbox"/>
Keep Alive Period:	10000

Contact CyberData Corporation



Technical Support

The fastest way to get technical support for your VoIP product is to submit a VoIP Technical Support form at the following website:

<http://support.cyberdata.net/>

Phone: (831) 373-2601, Ext. 333

Email: support@cyberdata.net

Fax: (831) 373-4193

Company and product information is at www.cyberdata.net

Additional Resources

CyberData VoIP Discovery Utility

<http://www.cyberdata.net/assets/common/discovery.zip>

CyberData VoIP Products

<http://www.cyberdata.net/voip-category/sip/>

GrandStream UCM 6100 Series Guides

<http://www.grandstream.com/support/resources/?title=UCM6100%20series>

GrandStream UCM 6102 Firmware

<http://www.grandstream.com/support/firmware>