





### Caution

*Equipment Hazard:* All equipment should be powered down prior to making wiring connections and changing switch positions.

### Grommes Precision GTC Series



### SIP Paging Adapter Connections



### Page Port Connections

| Pin | Description                                |
|-----|--|
| 1   | Fault Sense Input (Common).                |
| 2   | Fault Sense Input (Sense).                 |
| 3   | Positive 600-Ohm Audio Output <sup>a</sup> |
| 4   | Negative 600-Ohm Audio Output <sup>a</sup> |
| 5   | Audio Ground Reference.                    |
| 6   | Relay Contact - Common <sup>b</sup>        |
| 7   | Relay Contact - Normally Open <sup>b</sup> |

a. The 600-Ohm audio output of the page port is also suited for interfaces with lower input impedances.

b. 1 Amp at 30 VDC for continuous loads.

### Notes

2-conductor, shielded speaker wire is recommended.